

NEW
and Improved
Design!

DeLaval Clover™ Liner 12R+ Product Data



Up to 2,500 Milkings

Product Number: 64223082
DeLaval Clover™ Liner 12R+ FDA

Quantity: Bulk 100

Special Characteristics:

- Helps promote teat end health
- Fast, complete milk out
- Full grip
- Low mouth piece vacuum
- Adapts to the teat
- Highly durable cogwheel reinforcement

Recommended Herds:

- Short to average size teats (1.75"-2" teats)

Required Equipment:

- Clusters:
 - Nippled 12 mm milk inlets
- Average to heavy claws
- Original DeLaval 06 shell
- Jetter cup (one of the following):
 - 87376202 CIP Seal
 - 830452605 Jetter cup
 - 830605001 Wash rack

Contact your local DeLaval Dealer for more information

DeLaval Clover™ Liner 12R+

Technical Data



DeLaval Recommendations

- Claw Vacuum: 11.2" – 12.4" Hg; (38 - 42 kPa)
- Take-Off Setting:
 - 2X = 2.0 – 1.3 lbs/min; (900 – 600 g/min)
 - 3X = 2.3 – 1.6 lbs/min; (1,000 – 700 g/min)
- Pulsation ratio: 65/35. Beats/minute: 60
- Ensure nipples on claws are not sharp when installing new liners
- Care should be taken when loading or unloading the cluster into sharp / drilled / or NON-DeLaval CIP candlesticks
- Do not use retract function to remove clusters from wash racks
- Remove clusters from the cluster cleaners between milkings
- Ensure good tube alignment to secure good milking performance
- Use DeLaval milk filters and change according to recommendations to ensure high milk quality
- Ensure correct dosage of detergent according to DeLaval label recommendations
- Replace after 2,500 milkings or 180 washes, whichever comes first

Please note:
Using imitation 06 shells may result in poor teat treatment and massage due to improper length.

DeLaval Reserves the right to make changes to these specifications without notice.